

BEVERLY



9/26D BRIGHT
BRONZE/SATIN
CHROME

AVAILABLE FUNCTIONS

101 — Passage/Hall/Closet

Both knobs always free.

331 — Privacy/Bed/Bath

Both knobs locked or unlocked by turn button inside. Outside knob unlocked by emergency key.

531 — Keyed Entry Knob

Both knobs locked or unlocked by key outside or turn button inside.

581 — Storeroom/Vestibule

Outside unlocked only while key is turned. Inside always free.

12 — Inactive Trim, Surface mount or bolt through

For doors where only a pull is required. No operation